



Easy Guide to Standard Timer Programming

1 Input “Run Times” or “Minutes”

Divide the total minutes per station in half, third, or quarter for better soaking into soil.

Tip: To determine run times, reference the Grass, Tree or Shrub Watering Guides

2 Input “Start Time” or “Program Start”

Lawn programs should start when it is dark outdoors to minimize evaporation. Shrub and Tree irrigation can start when leaks are most likely to be seen.

Tip: You DO NOT need separate start times for each zone. All the zones will run one after the other with one start time.

Input additional times only if trying to run zones more than once in a day.

3 Input “Days” to run each program

Use the “Interval” or “INT” function on your timer to select days between watering. See Watering Guidelines for recommended days between watering.

Tip: If your run times and start times are all set, this setting is the ONLY one you need to adjust each month or season based on weather changes

4 GO: Use Programs A, B, C, as needed

Zone	PGM A	PGM B	PGM B
1 Trees & Shrubs	once every 10 days @ 9am		
2 Lawn		once every 5 days @ 1am & 3am	
3 Veggies			once every 7 days @ 5am

EXAMPLE
FALL
SEASON



Want a free monthly scheduling reminder?
Simply text WHENTOWATER to 1-844-416-1428

